


**SEPARATELY EXCITED (SX) TRANSISTORIZED MOTOR CONTROLLERS
 FOR PALLET JACK APPLICATION
 (GE MODEL IC3645SR2R404F1)
 INSTALLATION AND OPERATION MANUAL**



Note: The information contained herein is intended to assist OEM's, Dealers and Users of electric vehicles in the application, installation and service of GE solid-state controllers. This manual does not purport to cover all variations in OEM vehicle types. Nor does it provide for every possible contingency to be met involving vehicle installation, operation or maintenance. For additional information and/or problem resolution, please refer the matter to the OEM vehicle manufacturer through his normal field service channels. Do not contact GE directly for this assistance.

Table of Contents

Copyright by General Electric Company May 2000

| | | |
|--------------------|---|----------|
| Section 1.0 | INTRODUCTION | 4 |
| | 1.1 Motor Characteristics | 4 |
| | 1.2 Solid-State Reversing | 5 |
| | 1.3 Flexible System Application..... | 5 |
| | 1.4 More Features with Fewer Components | 5 |
| Section 2.0 | FEATURES OF SX FAMILY OF MOTOR CONTROLLERS | 5 |
| | 2.1 Performance..... | 5 |
| | 2.1.1 Oscillator Card Features | 5 |
| | 2.1.1.a Standard Operation | 5 |
| | 2.1.1.b Control Acceleration..... | 6 |
| | 2.1.2 Current Limit | 6 |
| | 2.1.3 Braking..... | 6 |
| | 2.1.3.a Plug Braking | 6 |
| | 2.1.3.b Regenerative Braking to Zero Speed | 6 |
| | 2.1.3.c Throttle Position Plug Braking..... | 6 |
| | 2.1.4 Auxiliary Speed Control..... | 6 |
| | 2.1.4.a Field Weakening..... | 6 |
| | 2.1.4.b Speed Limits | 6 |
| | 2.1.5 Ramp Operation | 7 |
| | 2.1.5.a Ramp Start | 7 |
| | 2.1.5.b Anti-Rollback..... | 7 |

Table of Contents (Continued)

| | | |
|--------------------|--|-----------|
| 2.1.6 | On-Board Coil Drivers and Internal Coil Suppression | 7 |
| 2.2 | System Protective Override | 7 |
| 2.2.1 | Static Return to Off (SRO) | 7 |
| 2.2.2 | Accelerator Volts Hold Off | 7 |
| 2.2.3 | Pulse Monitor Trip (PMT)..... | 7 |
| 2.2.4 | Thermal Protector (TP)..... | 7 |
| 2.2.5 | Low Voltage Detection..... | 7 |
| 2.3 | Diagnostics..... | 7 |
| 2.3.1 | Status Codes..... | 7 |
| 2.3.1.a | Standard Status Codes..... | 7 |
| 2.3.1.b | Stored Status Codes | 8 |
| 2.3.2 | Hourmeter Readings | 8 |
| 2.3.2.a | Maintenance Alert Status Code | 8 |
| 2.3.3 | Battery Discharge Indication (BDI)..... | 8 |
| 2.3.3.a | Internal Resistance Compensation | 8 |
| 2.3.4 | Handset | 8 |
| 2.3.5 | Circuit Board Coil Driver Modules..... | 8 |
| 2.3.6 | Selectable Truck Modes | 8 |
| Section 3.0 | ORDERING INFORMATION, ELEMENTARY AND OUTLINE DRAWINGS..... | 9 |
| 3.1 | Ordering Information for Separately Excited Controls..... | 9 |
| 3.2 | Outline: SX-2 Package Size..... | 10 |
| 3.3 | Standard Elementary for Pallet Jack Application | 11 |
| 3.4 | Standard Pallet Jack Application Input / Output List..... | 12 |
| Section 4.0 | TROUBLESHOOTING AND DIAGNOSTIC STATUS CODES..... | 13 |
| 4.1 | General Maintenance Instructions..... | 13 |
| 4.2 | Cable Routing and Separation | 13 |
| 4.2.1 | Application Responsibility | 13 |
| 4.2.2 | Signal/Power Level Definitions | 13 |
| 4.2.2.a | Low Level Signals (Level L) | 13 |
| 4.2.2.b | High Level Signals (Level H)..... | 14 |
| 4.2.2.c | Medium-Power Signals (Level MP) | 14 |
| 4.2.2.d | High-Power Signals (Level HP) | 14 |
| 4.2.3 | Cable Spacing Guidelines..... | 14 |
| 4.2.3.a | General Cable Spacing..... | 14 |
| 4.2.4 | Cabling for Vehicle Retrofits..... | 14 |
| 4.2.5 | RF Interference..... | 14 |
| 4.2.6 | Suppression..... | 14 |
| 4.3 | Recommended Lubrication of Pins and Sockets Prior to Installation..... | 15 |
| 4.4 | General Troubleshooting Instructions | 15 |
| 4.5 | Traction Controller Status Codes | 16-30 |
| Section 5.0 | SX FAMILY - GE HANDSET INSTRUCTIONS | 31 |
| 5.1 | General Features | 31 |
| 5.2 | Purpose/Setup Functions | 31 |
| 5.3 | Setup Function Procedures | 32 |
| 5.3.1 | Setup Mode | 32 |


Table of Contents (Continued)

| | | |
|--------------------|--|-----------|
| 5.3.2 | Status Code Scrolling..... | 32 |
| 5.3.3 | SX Handset Plug Connections & Outline Drawing..... | 32 |
| 5.4 | Setup Functions for Traction Controller .. | 33-38 |
| 5.5 | Summary of Current Limit Adjustments | 39 |
| Section 6.0 | DASH DISPLAYS..... | 40 |
| 6.1 | Application | 40 |
| 6.2 | Standard Dash Displays | 40 |
| 6.2.1 | Connections..... | 40 |
| 6.2.2 | Part Numbers | 40 |
| 6.2.3 | Connector Reference Numbers..... | 40 |
| 6.3 | Start-up Display Sequence | 40 |
| 6.4 | Outline Drawings | 41 |
| Section 7.0 | MEMORY MAPS..... | 42 |
| 7.1 | Typical Memory Map for Traction Control..... | 42-44 |

Section 1. INTRODUCTION

Section 1.1 Motor Characteristics

The level of sophistication in the controllability of traction motors has changed greatly over the past several years. Vehicle manufacturers and users are continuing to expect more value and flexibility in electric vehicle motor and control systems as they are applied today. In order to respond to these market demands, traction system designers have been forced to develop new approaches to reduce cost and improve functions and features of the overall system. Development is being done in a multi-generational format that allows the market to take advantage of today's technology, while looking forward to new advances on the horizon. GE has introduced a second generation system using separately excited DC shunt wound motors. The separately excited DC motor system offers many of the features that are generally found on the advanced AC systems. Historically, most electric vehicles have relied on series motor designs because of their ability to produce very high levels of torque at low speeds. But, as the demand for high efficiency systems increases, i.e., systems that are more closely applied to customers' specific torque requirements, shunt motors are now often being considered over series motors. In most applications, by independently controlling the field and armature currents in the separately excited motor, the best attributes of both the series and the shunt wound motors can be combined.




As shown in the typical performance curves of Figure 1, the high torque at low speed characteristic of the series motor is evident.


In a shunt motor, the field is connected directly across the voltage source and is therefore independent of variations in load and armature current. If field strength is held constant, the torque developed will vary directly with the armature current. If the mechanical load on the motor increases, the motor slows down, reducing the back EMF (which depends on the speed, as well as the constant field strength). The reduced back EMF allows the armature

current to increase, providing the greater torque needed to drive the increased mechanical load. If the mechanical load is decreased, the process reverses. The motor speed and the back EMF increase, while the armature current and the torque developed decrease. Thus, whenever the load changes, the speed changes also, until the motor is again in electrical balance.

In a shunt motor, the variation of speed from no load to normal full load on level ground is less than 10%. For this reason, shunt motors are considered to be constant speed motors (Figure 2).



In the separately excited motor, the motor is operated as a fixed field shunt motor in the normal running range. However, when additional torque is required, for example, to climb non-level terrain, such as ramps and the like, the field current is increased to provide the higher level of torque. In most cases, the armature to field ampere turn ratio can be very similar to that of a comparable size series motor (Figure 3.)



Aside from the constant horsepower characteristics described above, there are many other features that provide increased performance and lower cost. The following description provides a brief introduction to some of these features.

Section 1. 2 Solid-State Reversing

The direction of armature rotation on a shunt motor is determined by the direction in which current flows through the field windings. Because of the shunt motor field, typically only requires about 10% of the armature current at full torque, it is normally cost effective to replace the double-pole, double-throw reversing contactor with a low power transistor H-Bridge circuit (Figure 4).




Figure 4

By energizing the transistors in pairs, current can be made to flow in either direction in the field. The field and armature control circuits typically operate at 12KHZ to 15KHZ, a frequency range normally above human hearing. This high frequency, coupled with the elimination of directional contactors, provides for very quiet vehicle operation.

The line contactor is normally the only contactor required for the shunt motor traction circuit. This contactor is used for both pre-charge of the line capacitors and for emergency shut down of the motor circuit, in case of problems that would cause a full motor torque condition. The line can be energized and de-energized by the various logic combinations of the vehicle, i.e. activate on key, seat or start switch closure, and de-energize on time out of idle vehicle. Again, these options add to the quiet operation of the vehicle.

Section 1. 3 Flexible System Application

Because the shunt motor controller has the ability to control both the armature and field circuits independently, the system can normally be adjusted for maximum system efficiencies at certain operating parameters. Generally speaking, with the ability to independently control the field and armature, the motor performance curve can be maximized through proper control application.

Section 1. 4 More Features with Fewer Components

Field weakening with a series wound motor is accomplished by placing a resistor in parallel with the field winding of the motor. Bypassing some of the current flowing in the field into the resistor causes the field current to be less, or weakened. With the field weakened, the motor speed will increase, giving the effect of "overdrive". To change the "overdrive speed", it is necessary to change the resistor value. In a separately excited motor, independent control of the field current provides for infinite adjustments of "overdrive" levels, between the motor base speed and maximum weak field. The desirability of this feature is enhanced by the elimination of the contactor and resistor required for field weakening with a series motor.

With a separately excited motor, overhauling speed limit, or downhill speed, will also be more constant. By its nature, the shunt motor will try to maintain a constant speed downhill. This characteristic can be enhanced by increasing the field strength with the control. Overhauling load control works in just the opposite way of field weakening, as armature rotation slows with the increase of current in the field. An extension of this feature is a zero-speed detect feature which prevents the vehicle from free-wheeling down an incline, should the operator neglect to set the brake.

Regenerative braking (braking energy returned to the battery) may be accomplished completely with solid-state technology. The main advantage of regenerative braking is increased motor life. Motor current is reduced by 50% or better during braking while maintaining the same braking torque as electrical braking with a diode clamp around the armature. The lower current translates into longer brush life and reduced motor heating. Solid state regenerative braking also eliminates a power diode, current sensor and contactor from the circuit.

For GE, the future is now, as we make available a new generation of electric traction motor systems for electric vehicles having separately excited DC shunt motors and controls. Features that were once thought to be only available on future AC or brushless DC technology vehicles systems are now achievable and affordable.

Section 2. FEATURES OF SX FAMILY OF TRANSISTOR MOTOR CONTROLLERS

Section 2.1 Performance

Section 2.1.1 Oscillator Card Features

Section 2.1.1.a Standard Operation

The oscillator section of the card has two adjustable features, creep speed and minimum field current. With the accelerator at maximum ohms or volts, the creep speed can be adjusted by Function 2 of the Handset or a trimpot. The field control section allows the adjustment of the field weakening level in order to set the top speed of the motor. This top speed function (Minimum Field Current) is enabled when the armature current is less than the value set by Function 24 and the accelerator input voltage is less than 1 volt. Top Speed can be adjusted by Function 7 of the Handset or a trimpot.

The % ON-time has a range of approximately 0 to 100 percent. The SX controllers operate at a constant frequency and the % ON-time is controlled by the pulse width of the voltage/current applied to the motor circuits.

Section 2.1.1.b Control Acceleration

This feature allows for adjustment of the rate of time it takes for the control to accelerate to 100% applied battery voltage to the motor on hard acceleration. Armature C/A is adjusted by Function 3 from 0.1 to 6 seconds.

Section 2.1.2 Current Limit

This circuit monitors motor current by utilizing sensors in series with the armature and field windings. The information detected by the sensor is fed back to the card so that current may be limited to a preset value. If heavy load currents are detected, this circuit overrides the oscillator and limits the average current to a value set by Function 4 and Function 8 of the Handset. The C/L setting is based on the maximum thermal rating of the control. Because of the flyback current through Q6, the motor current is usually greater than battery current, except at 100% ON time.

Section 2.1.3 Braking

Section 2.1.3.a Plug Braking

Slow down is accomplished when reversing direction by providing a small amount of retarding torque for deceleration. If the vehicle is moving, and the directional lever is moved from one direction to the other, the plug signal is initiated. Once the plug signal has been initiated, the field is reversed, and the armature current is regulated to the plug current limit as set by Function 5. Armature current is regulated by increasing the field current as the vehicle slows down. Once the field current reaches a preset value, set by Function 10, and armature plug current can no longer be maintained, the braking function is canceled, and the control reverts back to motoring. All energy produced by the motor during plugging is dumped as heat into the motor in this braking mode.

Section 2.1.3.b Regenerative Braking to Zero Speed

Slow down is accomplished when reversing direction by providing a small amount of retarding torque for deceleration. If the vehicle is moving, and the directional lever is moved from one direction to the other, the regen signal is initiated. Once the regen signal has been initiated, the field current is increased. Armature current is regulated to the regen current limit as set by Function 9. As the vehicle slows down, the field current continues to increase, and transistor Q2 begins to chop. The field current will increase until it reaches a preset value set by Function 10, and transistor Q2 on-time will increase until it reaches 100% on-time. Once both of the above conditions have been met, and the regen current limit can no longer be maintained, the braking function is canceled. The fields will then reverse, and the control reverts back to motoring.

Part of the energy produced by the motor during regen is returned to the battery, and the remainder is dumped into the motor as heat.

Section 2.1.3.c Throttle Position Plug Braking

This feature allows control of the plugging distance based on throttle position when there has been a "directional switch" change. Throttle position will reduce the plugging current as the throttle is returned to the creep speed position. Maximum plug current is obtained with the accelerator in the top speed position.

Section 2.1.4 Auxiliary Speed Control

Section 2.1.4.a Field Weakening

This function allows the adjustment of the field weakening level in order to set the top speed of the motor. The function is enabled when the armature current is less than the value set by Function 24. It is important to note that this function is used to optimize motor and control performance, and this setting will be determined by GE and OEM engineers at the time of vehicle development. *This setting must not be changed by field personnel without the permission of the OEM.*

Section 2.1.4.b Speed Limits

This feature provides a means to control speed by limiting motor volts utilizing three "adjustable speed limits" initiated by individual limit switches. The NC switches are connected between input points on the control card and battery negative. The lower motor volt limit always takes priority when more than one switch input is open. This motor volt limit regulates top speed of the transistor controller, but actual truck speed will vary at any set point, depending on the loading of the vehicle. Each speed limit can be adjusted with the Handset using Functions 11, 12

and 13 for speed limits SL1, SL2 and SL3, respectively. SL1 is active in all card types, and must be disabled with the Handset, if speed limits are not used.

Section 2.1.5 Ramp Operation

Section 2.1.5.a Ramp Start

This feature provides maximum control torque to restart a vehicle on an incline. The memory for this function is the directional switch. When stopping on an incline, the directional switch must be left in its original or neutral position to allow the control to initiate full power when restarted. The accelerator potentiometer input will modulate ramp start current.

Section 2.1.5.b Anti-Rollback

This feature provides retarding torque to limit rollback speed in the non-travel direction when the ACC pedal is released when stopping on a grade, or when the brake pedal is released when starting on a grade. This feature forces the vehicle to roll very slowly down the grade when the accelerator or brake is released. Because the vehicle can gain significant speed during roll-back, the torque needed to re-start on the ramp is lower than an unrestricted roll-back speed.

Section 2.1.6 On-Board Coil Drivers and Internal Coil Suppression

Coil drivers for the LINE and SP or BYPASS contactors are on-board the control card. These contactors must have coils rated for the vehicle battery volts.

Section 2.2 System Protective Override

Section 2.2.1 Static Return to Off (SRO)

This inherent safety feature of the control is designed to require the driver to return the directional lever to the neutral position anytime he leaves the vehicle and returns. Additionally, if the seat switch or key switch is opened, the control shuts off and cannot be restarted until the directional lever is returned to neutral. A time delay of approximately 2 seconds is built into the seat switch input to allow momentary opening of the seat switch, if a bump is encountered.

Section 2.2.2 Accelerator Volts Hold Off

This feature checks the voltage level at the accelerator input whenever the key switch or seat switch is activated. If, at start-up, the voltage is greater than 0.9 volts, the control will not operate. This feature assures that the control is calling for low speed operation at start up.

Section 2.2.3 Pulse Monitor Trip (PMT)

The PMT design contains three features which shut down, or lock out, control operation if a fault conditions occurs that would cause a disruption of normal vehicle operation:

- Look ahead
- Look again
- Automatic look again and reset

The PMT circuit will not allow the control to start under the following conditions:

- The control monitors both armature and field FET's at start-up and during running.
- The control will not allow the line contactor to close at start-up, or will drop it out during running, if either the armature or field FET's are defective, so as to cause uncontrolled truck movement.

Section 2.2.4 Thermal Protector (TP)

This temperature sensitive device is internal to the power transistor (Q1) module. If the transistor's temperature begins to exceed the design limits, the thermal protector will lower the maximum current limit to 200 amps. As the control cools, the thermal protector will automatically reset, returning the control to full power.

Section 2.2.5 Low Voltage Detection

Batteries under load, particularly if undersized or more than 80 percent discharged, will produce low voltages at the control terminals. The SX control is designed for use down to 50 percent of a nominal battery voltage of 36-84 volts, and 75 percent of a nominal battery voltage of 24 volts. Lower battery voltage may cause the control to operate improperly, however, the resulting PMT should open the Line contactor, in the event of a failure.

Section 2.3 Diagnostics

Section 2.3.1 Status Codes

Section 2.3.1.a Standard Status Codes

The SX control has a wide variety of Status Codes that assist the service technician and operator in trouble shooting the vehicle. If mis-operation of the vehicle occurs, a status code will be displayed on the Dash Display for vehicles so equipped, or be available from the status code displayed when the Handset is plugged into the "Y" plug of the logic card.

With the status code number, follow the procedures outlined in DIAGNOSTIC STATUS CODES to determine the problem and appropriate corrective action.

Note: The Status Code Instruction Sheets do not purport to cover all possible causes of a display of a "status code". They do provide instructions for checking the most direct inputs that can cause status codes to appear.

Section 2.3.1.b Stored Status Codes

This feature records the last 16 "Stored Status Codes" that have caused a PMT controller shut down and/or disrupted normal vehicle operation. (PMT type faults are reset by cycling the key switch). These status codes, along with the corresponding BDI and hourmeter readings, can be accessed with the Handset, or by using the RS 232 communications port and dumping the information to a Personal Computer terminal.

Section 2.3.2 Hourmeter Readings

This feature will display the recorded hours of use of the traction and pump control to the Dash Display each time the key switch is turned off.

Section 2.3.2.a Maintenance Alert Status Code

This feature is used to display a "99" status code when the vehicle operating hours match the hours set into the maintenance alert register. This feature is set with the Handset using Functions 19 and 20. The operator is alerted that maintenance on the vehicle is required.

Section 2.3.3 Battery Discharge Indication (BDI)

The latest in microprocessor technology is used to provide accurate battery state of charge information and to supply passive and active warning signals to the vehicle operator. Features and functions:

- Displays 100 to 0 percent charge.
- Display blinks with 20% charge. Option to disable pump circuit with 9% charge. Auto ranging for 36/48 volt operation. Adjustable for use on 24 to 80 volts.

Section 2.3.3.a Internal Resistance Compensation

This feature is used when the Battery Discharge Indicator is present. Adjustment of this function optimizes BDI with among different brands of batteries.

Section 2.3.4 Handset

This is a multi-functional tool used with the LX, ZX, and SX Series GE solid state controls. The Handset consists of a Light Emitting Diode (LED) display and a keyboard for data entry. Note, for ordering purposes, a separate Handset part number is required for SX controls.

Features and functions:

- Monitor existing system status codes for both traction and pump controls. Monitor intermittent random status codes.
- Monitor battery state of charge, if available.
- Monitor hourmeter reading on traction and pump controls.
- Monitor or adjust the control functions.

Section 2.3.5 Circuit Board Coil Driver Modules

Coil drivers are internal to the control card, and are the power devices that operate the Line, 1A and SP contactor coils. On command from the control card, these drivers initiate opening and closing the contactor coils. All driver modules are equipped with reverse battery protection, such that, if the battery is connected incorrectly, the contactors can not be closed electrically.

Section 2.3.6 Selectable Truck Modes

Through the adjustment of Function 1 of the controller, the following truck parameters are automatically adjusted to the values set below:

| Description | Mode 1 | Mode 2 | Mode 3 | Mode 4 |
|-----------------------------|--|--|--|--|
| Function 1 Setting | 0 to 31 | 32 to 63 | 64 to 95 | 96 to 255 |
| Min Field Current | Function 48 of the Handset Function 97 of the Computer | Function 52 of the Handset Function 101 of the Computer | Function 56 of the Handset Function 105 of the Computer | Function 60 of the Handset Function 109 of the Computer |
| Field Weakening Start | Function 49 of the Handset Function 98 of the Computer | Function 53 of the Handset Function 102 of the Computer | Function 57 of the Handset Function 106 of the Computer | Function 61 of the Handset Function 110 of the Computer |
| Ratio | Function 50 of the Handset Function 99 of the Computer | Function 54 of the Handset Function 103 of the Computer | Function 58 of the Handset Function 107 of the Computer | Function 62 of the Handset Function 111 of the Computer |
| Regen Braking Current Limit | Function 51 of the Handset Function 100 of the Computer | Function 55 of the Handset Function 104 of the Computer | Function 56 of the Handset Function 108 of the Computer | Function 63 of the Handset Function 112 of the Computer |

Section 3.0 ORDERING INFORMATION, ELEMENTARY AND OUTLINE DRAWINGS

Section 3.1 Ordering Information for Separately Excited Controls

Example:

| | | | | | | | |
|---------------------|---------------|-----------|----------|----------|-----------|----------|-----------|
| Part Number: | IC3645 | SE | 4 | D | 33 | 2 | C3 |
| Argument Number: | 01 | 02 | 03 | 04 | 05 | 06 | 07 |

Argument 01: Basic Electric Vehicle Control Number

Argument 02: Control Type:
 SH = Separately Excited Control (Plugging)
 SR = Separately Excited Control (Regen to Zero)

Argument 03: Operating Voltage:

| | |
|---------------|-----------------|
| 1 = 120 volts | 5 = 36/48 volts |
| 2 = 24 volts | 6 = 24/36 volts |
| 3 = 36 volts | 7 = 72/80 volts |
| 4 = 48 volts | |

Argument 04: Package Size:

| |
|--------------------|
| D = 6.86" X 6.67" |
| R = 6.86" X 8.15" |
| U = 8.66" X 8.13" |
| W = 8.66" X 10.83" |

Argument 05: Armature Current
 (2 characters)

| |
|---------------|
| 22 = 220 Amps |
| 33 = 330 Amps |
| 40 = 400 Amps |

etc.

Argument 06: Field Current
 (1 character)

| |
|-------------|
| 2 = 20 Amps |
| 3 = 30 Amps |
| 4 = 40 Amps |


etc.

Argument 07: Customer / Revision


| |
|------------------------------|
| A1 = Customer A / Revision 1 |
| B1 = Customer B / Revision 1 |

etc.

Section 3.2 Outline: SX-2 Package Size



Section 3.3 Standard Elementary for Pallet Jack Application




Section 3.4


Standard Pallet Jack Application Input/Output List

Connections to Main Plug (23 Pin) and "Y" Plug (12 Pin)

| STANDARD PALLET JACK MAIN PLUG INPUT/OUTPUT DESCRIPTION | |
|--|--|
| 1 | BATTERY VOLTS FROM BATTERY |
| 2 | BATTERY VOLTS FROM KEY |
| 3 | BATTERY VOLTS FROM BELLY BUTTON SWITCH |
| 4 | BATTERY VOLTS FROM FORWARD SWITCH |
| 5 | BATTERY VOLTS FROM REVERSE SWITCH |
| 6 | BATTERY VOLTS FROM BRAKE SWITCH |
| 7 | ACCELERATOR INPUT VOLTAGE SIGNAL |
| 8 | ACCELERATOR NEGATIVE |
| 9 | ACCELERATOR POT +5 VOLTS SUPPLY |
| 10 | N/A |
| 11 | N/A |
| 12 | BATTERY VOLTS JOG SWITCH |
| 13 | N/A |
| 14 | N/A |
| 15 | N/A |
| 16 | N/A |
| 17 | LINE CONTACTOR DRIVER |
| 18 | PUMP CONTACTOR DRIVER |
| 19 | N/A |
| 20 | N/A |
| 21 | BATTERY VOLTS FROM JACK RABBIT SWITCH |
| 22 | N/A |
| 23 | N/A |
| MOTOR TRACTION "Y" PLUG INPUT/OUTPUT DESCRIPTION | |
| 1 | CLOCK (OUT) (DASH DISPLAY-4) |
| 2 | DATA (OUT) (DASH DISPLAY-3) |
| 3 | ENABLE (OUT) (DASH DISPLAY-1) |
| 4 | NEGATIVE (DASH DISPLAY-2) |
| 5 | +5V SUPPLY (DASH DISPLAY-5) |
| 6 | CONT/STORE (IN) (HANDSET) |
| 7 | MOTOR CURRENT |
| 8 | VALUE (IN)(HANDSET) |
| 9 | FUNCTION (IN)(HANDSET) |
| 10 | N/A |
| 11 | SERIAL PORT (RECEIVE) |
| 12 | SERIAL PORT (TRANSMIT) |



WIRE END VIEW "Y" PLUG



WIRE END VIEW - MAIN PLUG

Section 4.0 TROUBLESHOOTING AND DIAGNOSTIC STATUS CODES

Section 4.1 General Maintenance Instructions

The transistor control, like all electrical apparatus, does have some thermal losses. The semiconductor junctions have finite *temperature* limits, above which these devices may be damaged. For these reasons, normal maintenance should guard against any action which will expose the components to excessive heat and/or those conditions which will reduce the heat dissipating ability of the control, such as restricting air flow.

The following Do's and Don't's should be observed:

Any controls that will be applied in ambient temperatures over 100° F (40° C) should be brought to the attention of the vehicle manufacturer.

All external components having inductive coils must be filtered. Refer to vehicle manufacturer for specifications.

The wiring should not be directly steam cleaned. In dusty areas, blow low-pressure air over the control to remove dust. In oily or greasy areas, a mild solution of detergent or denatured alcohol can be used to wash the control, and then low-pressure air should be used to completely dry the control.

For the control to be most effective, it must be mounted against the frame of the vehicle. The metal vehicle frame, acting as an additional heat sink, will give improved vehicle performance by keeping the control package cooler. *Apply a thin layer of heat-transfer grease (such as Dow Corning 340) between the control heat sink and the vehicle frame.*

Control wire plugs and other exposed transistor control parts should be kept free of dirt and paint that might change the effective resistance between points.

CAUTION: The vehicle should not be plugged when the vehicle is jacked up and the drive wheels are in a free wheeling position. The higher motor speeds can create excessive voltages that can be harmful to the control.

Do not hipot (or megger) the control. Refer to control manufacturer before hipotting.

Use a lead-acid battery with the voltage and ampere hour rating specified for the vehicle. Follow normal battery maintenance procedures, recharging before 80 percent discharged with periodic equalizing charges.

Visual inspection of GE contactors contained in the traction and pump systems is recommended to occur during every

160 hours of vehicle operation. Inspection is recommended to verify that the contactors are not binding and that the tips are intact and free of contaminants.

GE does not recommend that any type of welding be performed on the vehicle after the installation of the control(s) in the vehicle. GE will not honor control failures during the warranty period when such failures are attributed to welding while the control is installed in the vehicle.

Section 4.2 Cable Routing and Separation

Electrical noise from cabling of various voltage levels can interfere with a microprocessor-based control system. To reduce this interference, GE recommends specific cable separation and routing practices, consistent with industry standards.

Section 4.2.1 Application Responsibility

The customer and customer's representative are responsible for the mechanical and environmental locations of cables. They are also responsible for applying the level rules and cabling practices defined in this section. To help ensure a lower cost, noise-free installation, GE recommends early planning of cable routing that complies with these level separation rules.

On new installations, sufficient space should be allowed to efficiently arrange mechanical and electrical equipment. On vehicle retrofits, level rules should be considered during the planning stages to help ensure correct application and a more trouble-free installation.

Section 4.2.2. Signal/Powerlevel Definitions

The signal/power carrying cables are categorized into four defining levels: low, high, medium power, and high power. Within those levels, signals can be further divided into classes.

Sections 4.2.2.a through 4.2.2.d define these levels and classes, with specific examples of each. Section 4.2.3 contains recommendations for separating the levels.

Section 4.2.2.a Low-Level Signals (Level L)

Low-level signals are designated as *level L*. These consist of:

- Analog signals 0 through ± 15 V
- Digital signals whose logic levels are less than 15 V DC
- 4 – 20 mA current loops
- DC busses less than 15 V and 250 mA

The following are specific examples of level L signals used in drive equipment cabling:

- Control common tie
- DC buses feeding sensitive analog or digital hardware

- All wiring connected to components associated with sensitive analog hardware with less than 5V signals (for example, potentiometers and tachometers)
- Digital tachometers and resolvers
- Dash display cabling
- RS-232 cabling

Note: Signal inputs to analog and digital blocks should be run as shielded twisted-pair (for example, inputs from tachometers, potentiometers, and dash displays).

Section 4.2.2.b High-Level Signals (Level H)

High-level signals are designated as *level H*. These signals consist of:

- Analog and digital signals greater than 15 V DC and less than 250 mA

For example, switch inputs connected to battery volts are examples of level H signals used in drive equipment cabling.

Section 4.2.2.c Medium-Power Signals (Level MP)

Medium power signals are designated as *level MP*. These signals consist of:

- DC switching signals greater than 15 V
- Signals with currents greater than 250 mA and less than 10A

The following are specific examples of level MP signals used in drive equipment cabling:

- DC busses less than 10 A
- Contactor coils less than 10 A
- Machine fields less than 10 A

Section 4.2.2.d High Power Signals (Level HP)

Power wiring is designated as *level HP*. This consists of DC buses and motor wiring with currents greater than 10 A. The following are specific examples of level HP signals used in drive equipment cabling:

- Motor armature loops
- DC outputs 10 A and above
- Motor field loops 10 A and above

Section 4.2.3. Cable Spacing Guidelines

Recommended spacing (or clearance) between cables (or wires) is dependent on the level of the wiring inside them. For correct level separation when installing cable, the customer must apply the **general guidelines** (section 4.2.3.a), outlined below.

Section 4.2.3.a General Cable Spacing

The following general practices should be used for *all levels* of cabling:

- All cables and wires of like signal levels and power levels must be grouped together.
- In general, different levels must run in separate wire bundles, as defined in the different classes, identified above. Intermixing cannot be allowed, unless noted by exception.
- Interconnecting wire runs should carry a level designation.
- If wires are the same level and same type signal, group those wires from one location to any other location together in multiconductor cables or bind them together with twine or zip-ties.
- When unlike signals must cross, cross them in 90° angles at a maximum spacing. Where it is not possible to maintain spacing, place a grounded steel barrier between unlike levels at the crossover point.

Section 4.2.4 Cabling for Vehicle Retrofits

Reducing electrical noise on vehicle retrofits requires careful planning. Lower and higher levels should never encircle each other or run parallel for long distances. It is practical to use existing wire runs or trays as long as the level spacing (see section 4.2.2) can be maintained for the full length of the run.

Existing cables are generally of high voltage potential and noise producing. Therefore, route levels L and H in a path separate from existing cables, whenever possible. For level L wiring, use barriers in existing wire runs to minimize noise potential.

Do not loop level L signal wires around level H, level MP, or HP wires.

Section 4.2.5 RF Interference

To prevent radio frequency (RF) interference, care should be taken in routing power cables in the vicinity of radio-controlled devices.

Section 4.2.6 Suppression

Unless specifically noted otherwise, suppression (for example, a snubber) is required on all inductive devices controlled by an output. This suppression minimizes noise and prevents damage caused by electrical surges.

Section 4.3 Recommended Lubrication of Pins and Sockets Prior to Installation

Beginning in January of 1999, GE will implement the addition of a lubricant to all connections using pins and sockets on EV100/EV200 and Gen II products. Any connection made by GE to the A, B, X, Y, or Z plugs will have the lubricant NYE 760G added to prevent fretting of these connections during vehicle operation.

Fretting occurs during microscopic movement at the contact points of the connection. This movement exposes the base metal of the connector pin which, when oxygen is present, allows oxidation to occur. Sufficient build up of the oxidation can cause intermittent contact and intermittent vehicle operation. This can occur at any similar type of connection, whether at the control or in any associated vehicle wiring, and the resultant intermittent contact can provide the same fault indication as actual component failure.

The addition of the NYE 760G lubricant will prevent the oxidation process by eliminating the access of oxygen to the contact point. GE recommends the addition of this lubricant to the 12 pin and 23 pin plugs of all new Gen II controls at the time of their installation into a vehicle.

When servicing existing vehicles exhibiting symptoms of intermittent mis-operation or shutdown by the GE control, GE recommends the addition of this lubricant to all 12 and 23 pin plugs, after proper cleaning of the connectors, as a preventative measure to insure fretting is not an issue before GE control replacement.

Section 4.4 General Troubleshooting Instructions

Trouble-shooting the SX family of controls should be quick and easy when following the instructions outlined in the following status code instruction sheets.

If mis-operation of the vehicle occurs, a status code will be displayed on the Dash Display (for vehicles equipped with a Dash Display) or made available by plugging a Handset into the plug "Y" location, and then reading the status code.

With the status code number, follow the procedures outlined in the status code instruction sheets to determine the problem.

Important Note: Due to the interaction of the logic card with all vehicle functions, almost any status code or control fault could be caused by the logic card. After all other status code procedures have been followed and no problem is found, the controller should then be replaced as the last option to correct the problem.

The same device designations have been maintained on different controls but the wire numbers may vary. Refer to

the elementary and wiring diagrams for your specific control. The wire numbers shown on the elementary diagram will have identical numbers on the corresponding wiring diagrams for a specific vehicle, but these numbers may be different from the numbers referenced in this publication.

WARNING: Before trouble-shooting, jack up the drive wheels, disconnect the battery and discharge the capacitors. Reconnect the battery as needed for specific checks. Capacitors should be discharged by connecting a 200 ohm 2 watt resistor between the positive and negative terminals on the control panel.


Check resistance on R x 1000 scale from frame to power and control terminals. A resistance of less than 20,000 ohms can cause misleading symptoms. Resistance less than 1000 ohms should be corrected first.

Before proceeding, visually check for loose wiring, mis-aligned linkage to the accelerator switch, signs of overheating of components, etc.


Tools and test equipment required are: clip leads, volt-ohm meter (20,000 ohms per volt) and basic hand tools.

Section 4.5 Traction Control Status Codes

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| NONE | Segments do not illuminate on the Dash Display and/or the Handset. | No input voltage to the control card or the display unit. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Display screen on Dash Display and/or Handset is blank.</p> <p>POSSIBLE CAUSE Positive or negative control voltage is not present.</p> <ul style="list-style-type: none"> • Insure that the key switch is closed and voltage is present between P1 & battery negative (Power Terminal "NEG"). Also check for voltage between P2 and control negative. <p>Open circuit between control card Plug Y & the Dash Display or Handset.</p> <ul style="list-style-type: none"> • Check for an open circuit or loose connection going from the "Y" plug and the Dash Display or Handset. <p>Defective Dash Display or Handset.</p> <ul style="list-style-type: none"> • Replace Dash Display or Handset. | |



| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -02 | Forward directional switch is closed on initial power up. | This status code will be displayed when P4 is greater than 60% of battery voltage at initial key switch on. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate because of Static Return to Off (SRO) lock out.</p> <p>POSSIBLE CAUSE Forward directional switch is closed on initial start up (i.e. closure of battery, key switch or foot switch).</p> <ul style="list-style-type: none"> • Return directional switch lever to neutral and then return lever to forward position. <p>Forward directional switch is welded closed or mis-adjusted to be held closed.</p> <ul style="list-style-type: none"> • Replace or adjust directional switch to insure that it opens when the directional switch is returned to neutral. <p>Short circuit between P3 and P4.</p> <ul style="list-style-type: none"> • Disconnect the wire from P4 and check for a short circuit between P3 and the wire that was connected to P4. <p>Defective control.</p> <ul style="list-style-type: none"> • Replace the controller unit. | |



| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -03 | Reverse directional switch is closed on initial power up. | This status code will be displayed when P5 is greater than 60% of battery voltage at initial key switch on. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate because of Static Return to Off (SRO) lock out.</p> <p>POSSIBLE CAUSE Reverse directional switch is closed on initial start up (i.e. closure of battery, key switch or foot/deadman switch).</p> <ul style="list-style-type: none"> Return directional switch lever to neutral and then return lever to reverse position. <p>Reverse directional switch is welded closed or mis-adjusted to be held closed.</p> <ul style="list-style-type: none"> Replace or adjust directional switch to insure that it opens when the directional switch is returned to neutral. <p>Short circuit between P3 and P5.</p> <ul style="list-style-type: none"> Disconnect the wire from P5 and check for a short circuit between P3 and the wire that was connected to P5. <p>Defective control. Replace the controller unit.</p> | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|--|
| -04 | Belly button switch is closed on start up. | This status code will be displayed when P3 is less than 50% of battery voltage when belly button switch is closed. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate.</p> <p>POSSIBLE CAUSE Defective belly button switch circuit.</p> <ul style="list-style-type: none"> Check belly button switch to insure that it is open when brake handle is pulled down. Check for open circuit or loose connections in wiring from key switch to brake switch and from P3 to brake switch. | |


| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|--|
| -06 | Accelerator depressed with no direction selected. | This status code will be displayed when P4 and P5 are less than 60% of battery volts, and P7 is less than 2.5 volts. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate.</p> <p>POSSIBLE CAUSE Accelerator pedal is depressed before closing forward or reverse directional switch.</p> <ul style="list-style-type: none"> Status code will disappear when directional switch is closed or when accelerator pedal is released. <p>Defective directional switch.</p> <ul style="list-style-type: none"> Check forward or reverse switch to insure closure when direction is selected. <p>Open circuit between directional switch(es) and battery positive or between directional switch(es) and P4 or P5.</p> <ul style="list-style-type: none"> Check all control wires and connections shown in Trouble Shooting Diagram. | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -07 | Accelerator input voltage too high. | This status code will be displayed when the accelerator input voltage at P7 is higher than 4.2 volts, and travel enable switch is selected. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate when accelerator pedal is depressed or status code -07 is displayed then disappears when the vehicle starts to accelerate.</p> <p>POSSIBLE CAUSE Accelerator input mis-adjusted or defective.</p> <ul style="list-style-type: none"> Input voltage at P7 should be less than 3.7 volts. Adjust or replace accelerator unit to insure that the voltage at P7 will vary from 3.5 volts to less than .5 volts when the pedal is depressed. <p>Open circuit between battery negative and P7 in accelerator input circuit.</p> <ul style="list-style-type: none"> Check for broken wires or loose connections or open potentiometer / voltage supply. <p>Short circuit from battery positive to wiring in accelerator input circuit.</p> <ul style="list-style-type: none"> Disconnect wire from P7 and measure voltage at wire to negative. Should be zero volts for potentiometer type and less than 3.7 volts for solid state type accelerator input. | |


| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|---|
| -08 | Accelerator input voltage too low on power up after initial key switch closure. | This status code will be displayed when the accelerator input voltage at P7 is less than 3.0 volts, and any of the following connections are opened and closed: battery plug or key switch. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Accelerator input mis-adjusted or defective.</p> <ul style="list-style-type: none"> Input voltage at P7 should be more than 3.0 volts. Adjust or replace accelerator unit to insure that the voltage at P7 is more than 3.0 volts before depressing pedal. <p>Short circuit between battery negative and TB1 in accelerator input circuit.</p> <ul style="list-style-type: none"> Disconnect wire from P7. Check for short circuit from wire to battery negative. Resistance should be greater than 4.7K ohms. <p>Defective control.</p> <ul style="list-style-type: none"> Disconnect wire from P7. Measure voltage from TB1 to negative. Voltage should be greater than 4.5 volts, if not, replace control. | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -09 | The travel enable switch is open and the directional switch is closed. | This status code will be displayed when P5 is less than 12% of battery volts and P4 is greater than 12% of battery volts. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Forward or reverse directional switch welded closed or mis-adjusted to be held closed.</p> <ul style="list-style-type: none"> Replace or adjust directional switches to insure that they open when directional switch is returned to neutral. <p>Short circuit between battery positive and P4 and/or P5.</p> <ul style="list-style-type: none"> Disconnect wires from P4 and P5 and check wire for short circuit to positive side of directional switch. <p>Defective Control</p> <ul style="list-style-type: none"> Disconnect wires and measure voltage at P4 and P5. Voltage should be less than 60% of battery volts. | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -14 | Jog switch is closed on start up. | This status code will be displayed when P12 is greater than 50% of battery volts at key on. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate due to SRO lockout.</p> <p>POSSIBLE CAUSE Jog switch is closed on initial start up.</p> <ul style="list-style-type: none"> Return jog switch to neutral position. <p>Jog switch is welded or misadjusted to be held closed.</p> <ul style="list-style-type: none"> Adjust or replace jog switch. <p>Defective control</p> <ul style="list-style-type: none"> Replace controller unit. | |



| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|--|
| -15 | Battery voltage is too low or control card is mis-adjusted. | This status code will be displayed when the battery volts are less than 1.95 volts per cell at initial key switch on. See table below. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate.</p> <p>POSSIBLE CAUSE Discharged battery</p> <ul style="list-style-type: none"> Check battery for proper open circuit voltage as shown in "Trouble Shooting Diagram", charge battery, if required. <p>Defective battery</p> <ul style="list-style-type: none"> Check each battery cell for proper voltage (greater than 1.95 volts at cell). Replace or repair battery. <p>Incorrect control card adjustment.</p> <ul style="list-style-type: none"> Check Function 15 for proper adjustment for battery being used. See Handset instruction sheet for details. Adjust to proper settings. <p>Check "minimum" battery volts at P1 and NEG.</p> | |



| NOMINAL BATTERY VOLTAGE | MINIMUM LIMIT VOLTS AT 1.95 VDC PER CELL |
|-------------------------|--|
| 24 | 23.4 |
| 36 | 35.1 |
| 48 | 46.8 |
| 72 | 70.2 |
| 80 | 78.0 |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION | | | | | | | | | | | | |
|--|---|--|-------------------------|--|----|------|----|------|----|------|----|------|----|------|
| -16 | Battery voltage is too high or control card is mis-adjusted. | This status code will be displayed when the battery volts are greater than 2.4 volts per cell at initial key switch on. See table below. | | | | | | | | | | | | |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> | | | | | | | | | | | | |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Incorrect control card adjustment Check Function 15 for proper adjustment for battery being used. See Handset instructions for details. Adjust to proper setting.</p> <p>Battery over charged or incorrect battery used.</p> <ul style="list-style-type: none"> • Check battery for proper open circuit voltage per table at right. If voltage is excessive, check battery charger for proper output voltage. <p>Check "maximum" battery volts at P1 and NEG.</p> | <table border="1" style="float: right;"> <thead> <tr> <th>NOMINAL BATTERY VOLTAGE</th> <th>MAXIMUM LIMIT VOLTS AT 2.40 VDC PER CELL</th> </tr> </thead> <tbody> <tr> <td>24</td> <td>28.8</td> </tr> <tr> <td>36</td> <td>43.2</td> </tr> <tr> <td>48</td> <td>57.6</td> </tr> <tr> <td>72</td> <td>86.4</td> </tr> <tr> <td>80</td> <td>96.0</td> </tr> </tbody> </table> | NOMINAL BATTERY VOLTAGE | MAXIMUM LIMIT VOLTS AT 2.40 VDC PER CELL | 24 | 28.8 | 36 | 43.2 | 48 | 57.6 | 72 | 86.4 | 80 | 96.0 |
| NOMINAL BATTERY VOLTAGE | MAXIMUM LIMIT VOLTS AT 2.40 VDC PER CELL | | | | | | | | | | | | | |
| 24 | 28.8 | | | | | | | | | | | | | |
| 36 | 43.2 | | | | | | | | | | | | | |
| 48 | 57.6 | | | | | | | | | | | | | |
| 72 | 86.4 | | | | | | | | | | | | | |
| 80 | 96.0 | | | | | | | | | | | | | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -23 | Motor field current is high on start up in the reverse direction. | This status code will be displayed when the current draw in the motor field is too high at start up in the reverse direction. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | <p>NO GRAPHIC FOR THIS STATUS CODE</p> |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -24 | Motor field current is high on start up in the forward direction. | This status code will be displayed when the current draw in the motor field is too high at start up in the forward direction. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | <p>NO GRAPHIC FOR THIS STATUS CODE</p> |


| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|---|
| -27 | Power supply is less than 10 Volts DC. | This status code will be displayed when the power supply is less than 10 volts. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Line contactor opens and closes, then can only be closed by opening and closing the key switch.</p> <p><u>POSSIBLE CAUSE</u> Discharged Battery</p> <ul style="list-style-type: none"> • Check battery to insure proper state of charge. Voltage may be dropping below 10 Volts DC under load. <p>Loose connection at P1.</p> <ul style="list-style-type: none"> • Insure that the wire connection at P1 is tight. <p>Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | <p>The diagram shows a power supply circuit. On the left is a battery symbol. A wire goes from the positive terminal of the battery to a fuse labeled 'FU3'. After the fuse, the wire goes to a 'KEY SWITCH'. From the other side of the key switch, the wire goes to a terminal labeled 'P1'. Another wire goes from the negative terminal of the battery to a terminal labeled 'NEG'. A third wire goes from terminal 'P2' to terminal 'NEG'. The circuit is completed by a wire from 'NEG' back to the negative terminal of the battery.</p> |


| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|---|
| -28 | Motor field current is too high during the run mode. | This status code will be displayed when the current draw in the motor field is sustained above a preset limit for longer than 35 seconds. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Continued operation of vehicle in high motor current condition.</p> <ul style="list-style-type: none"> Operate vehicle at lower motor current condition for 35 seconds. <p>Function 7 is mis-adjusted to allow higher than normal motor field current.</p> <ul style="list-style-type: none"> Adjust this function per OEM instructions. | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -41 | Open thermal protector (TP) or transistor over temperature. | This status code will be displayed when the voltage at the thermal protector is too high. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Reduced or no power to traction motor in control range.</p> <p><u>POSSIBLE CAUSE</u> Control is in thermal cut-back.</p> <ul style="list-style-type: none"> Allow control to cool, status code should disappear. <p>Defective control.</p> <ul style="list-style-type: none"> Replace controller unit. | <p style="text-align: center;">NO GRAPHIC FOR THIS STATUS CODE</p> |


| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -42 | Motor armature offset voltage is too high. | This status code will be displayed when the voltage at the current sensor input is greater than 2.6 volts with no current flowing in the motor circuit. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | NO GRAPHIC FOR THIS STATUS CODE |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|--|
| -43 | Motor armature offset voltage is too low. | This status code will be displayed when the voltage at the current sensor input is less than 2.4 volts with no current flowing in the motor circuit. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | NO GRAPHIC FOR THIS STATUS CODE |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|--|
| -44 | Armature transistor did not turn off properly. | This status code will be displayed when, during control operation, the armature transistor fails to turn off. This will result in a PMT condition. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM  |
| Circuits valid for Traction Controller | <p>SYMPTOM Line contactor opens and closes, then can only be closed by opening and closing the key switch.</p> <p>POSSIBLE CAUSE Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|--|
| -45 | Armature transistor did not turn on properly. | This status code will be displayed when, during control operation, the armature transistor fails to turn on properly. This will result in a PMT condition. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM  |
| Circuits valid for Traction Controller | <p>SYMPTOM Line contactor open and closes, then can only be closed by opening and closing the key switch.</p> <p>POSSIBLE CAUSE Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|--|
| -46 | "Look Ahead" test for A2 volts less than 12% of battery volts. | This status code will be displayed when the voltage at A2 is less than 12% of battery volts. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Line contactor will not pick up.</p> <p><u>POSSIBLE CAUSE</u> Check for short circuit from the motor armature to the frame of the vehicle.</p> <p>Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | |





| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|---|
| -49 | Motor field current is too low during the run mode. | This status code will be displayed when the current draw in the motor field is too low during the run mode. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Control will not operate.</p> <p><u>POSSIBLE CAUSE</u> Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | |


NO GRAPHIC FOR THIS STATUS CODE


| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|---|
| -51 | Capacitor volts are low before the line contactor closes. | This status code will be displayed during "key on" when the capacitor volts is less than 85% of battery volts at initial key switch on. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Line contactor does not close when capacitor does not precharge.</p> <p>POSSIBLE CAUSE Defective control fuse.</p> <ul style="list-style-type: none"> • Check control fuse for open circuit. Replace fuse, if necessary. <p>Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|--|
| -57 | Controller "motor current sensor" input too low during running. | This status code will be displayed when the voltage input from the current sensor is too low during running. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate.</p> <p>POSSIBLE CAUSE Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit. | <p style="text-align: center;">NO GRAPHIC FOR THIS STATUS CODE</p> |


| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|---|
| -64 | The line driver input (P2-17) is less than 12% of battery volts | This status code will be displayed when the control detects that the line driver input (P2-17) is less than 12% battery volts when the key switch is turned on. |
| MEMORY RECALL NO | CORRECTIVE ACTIONS | TRUBLE-SHOOTING DIAGRAM  |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate.</p> <p>POSSIBLE CAUSE - Open wire connection to Pin 17 - Shorted line Driver transistor</p> <p>Defective control. • Replace controller unit.</p> | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|--|
| -65 | The line coil current is too high during the run mode | This status code will be displayed when the current limit in the line coil is exceeded during the run mode. The line contactor will drop out and the key switch will have to be recycled to reset the control. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | TRUBLE-SHOOTING DIAGRAM  |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate.</p> <p>POSSIBLE CAUSE - Shorted line contactor coil - Short between wires connected to line coil</p> <p>If line coil resistance is correct: Defective control. • Replace controller unit.</p> | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|---|
| -66 | The field current exceeds the current limit of the field transistor. | This status code will be displayed when the field transistor exceeds its specific current limit. The line contactor will drop out and the key switch will have to be recycled to restart the control. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM  |
| Circuits valid for Traction Controller | <p>SYMPTOM Control will not operate</p> <ul style="list-style-type: none"> Line contactor opens <p>POSSIBLE CAUSE</p> <ul style="list-style-type: none"> Shorted field F1 to F2 F1 or F2 terminals shorted to battery positive (B+) F1 or F2 terminals shorted to battery negative (B-) | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION | | | | | | | |
|--|--|---|-------|-----------------|-----|-----|-----|-----|-----|
| -76 | Capacitor (1C) voltage too high. | This status code will be displayed when the voltage on the capacitor goes above limit voltage* during the regenerative braking cycle. | | | | | | | |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | TROUBLE-SHOOTING DIAGRAM  | | | | | | | |
| Circuits valid for Traction Controller | <p>SYMPTOM Line contactor opens and closes, then opens and can only close by opening and closing the key switch.</p> <p>POSSIBLE CAUSE</p> <ul style="list-style-type: none"> Unplugging the battery connector during regenerative braking. Line contactor bouncing open during regen. Main power fuse opening during regen. Intermittent battery plug connection. <p>* Limit Voltage:</p> <table border="1" data-bbox="422 1722 665 1837"> <thead> <tr> <th>Limit</th> <th>Battery Voltage</th> </tr> </thead> <tbody> <tr> <td>50V</td> <td>36V</td> </tr> <tr> <td>70V</td> <td>48V</td> </tr> <tr> <td>96V</td> <td>72//80V</td> </tr> </tbody> </table> | | Limit | Battery Voltage | 50V | 36V | 70V | 48V | 96V |
| Limit | Battery Voltage | | | | | | | | |
| 50V | 36V | | | | | | | | |
| 70V | 48V | | | | | | | | |
| 96V | 72//80V | | | | | | | | |

| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|---|--|
| -77 | Motor current is detected during regenerative braking. | This status code will be displayed when motoring current is detected during the regen braking cycle. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Line contactor opens and closes, then opens and can only close by opening and closing the key switch.</p> <p><u>POSSIBLE CAUSE</u> Defective control.</p> <ul style="list-style-type: none"> • Replace controller unit | |



| TRACTION STATUS CODE | DESCRIPTION OF STATUS | CAUSE OF STATUS INDICATION |
|--|--|--|
| -99 | Maintenance alert and speed limit. | This status code will be displayed when the “normal” hour meter exceeds the “maintenance alert hours” setting for the vehicle. |
| MEMORY RECALL YES | CORRECTIVE ACTIONS | <u>TROUBLE-SHOOTING DIAGRAM</u> |
| Circuits valid for Traction Controller | <p><u>SYMPTOM</u> Status code is displayed for 4 seconds when the key switch is first turned on, and/or the vehicle may run at a reduced speed.</p> <p><u>CUSTOMER SELECTED SETTING WITH THE HANDSET:</u> User defined status code is displayed when the normal hour meter reading exceeds the programmed “maintenance alert hours” setting selected by the user.</p> <ul style="list-style-type: none"> • Maintenance Code Hour Meter, Functions 19 and 20, are programmed with the Handset and command the display of status code -99. • If desired, Maintenance Code Speed Limit, Function 21, can be programmed with the Handset. <p>User should perform the desired maintenance function. Re-set maintenance alert hour meter after maintenance is performed.</p> | |

NO GRAPHIC AVAILABLE FOR THIS STATUS CODE

USER SHOULD PERFORM THE DESIRED MAINTENANCE FUNCTION

Section 5. SX FAMILY GE HANDSET INSTRUCTIONS

Section 5.1 General Features

The GE Handset is a multi-functional tool to be used with the LX, ZX, and SX Series GE solid-state controls. The Handset consists of a Light Emitting Diode (LED) display and a keyboard for data entry.

Note: The Handset is the same for all GE controls, however, the cable will change between some control types.


Section 5.2 Purpose / Setup Functions

The purpose of the Handset is to allow authorized personnel to perform the following functions of the SX family of Controls:

- Monitor existing system fault codes
- Monitor intermittent random fault codes
- Monitor battery state of charge on systems with BDI
- Monitor hourmeter reading
- Monitor or adjust the following control functions:
 - ◆ Creep speed
 - ◆ Armature Controlled Acceleration and 1A Time
 - ◆ Regenerative Braking Current Limit and Disable
 - ◆ Armature and Field Current Limit
 - ◆ Plugging Distance (Current)
 - ◆ Pedal Position Plug Range or Disable
 - ◆ 1A Drop Out Current or Disable
 - ◆ Speed Limit Points
 - ◆ Truck Management Fault Speed Limit
 - ◆ Internal Resistance Compensation for Battery State of Charge Indication
 - ◆ Battery Voltage (36/48 volts is auto ranging)
 - ◆ Selection of Card Operation Type.

Warning: Before connecting or disconnecting the Handset tool, turn off the key switch, unplug the battery and jack up the drive wheels of the vehicle.

At the transistor control traction card, unplug the "Y plug" if the dash display is in use, and plug in the Handset to the plug location "Y" on the control card. After installing the Handset tool, plug the battery in and turn the key switch on. The following is the start-up display sequence that will occur:



NOTE: The vehicle can be operated with the Handset connected, however, the adjustment knob must be set fully clockwise to insure the control operates at top speed.

Warning: Before making any adjustments to the control, you must consult the operating and maintenance instructions supplied by the vehicle manufacturer. Failure to follow proper set up instructions could result in mis-operation or damage to the control system.

Section 5.3 Set-up Function Procedures

With the Handset connected, hold down the **CONT** key and turn on the key switch. This will place you in the set-up mode, ready to monitor or adjust control function settings.

NOTE: The term "Push" means to depress key for approximately one second.

Section 5.3.1 Setup Mode

| SET-UP MODE | | |
|-----------------------------------|----------------|--|
| ACTION | DISPLAY SHOWS | REMARKS |
| Hold Down CONT And Turn On Key | 8 8 8 8 | Segment Check Displayed |
| Push Function Number | U 0 0 5 | Selected Function No. Is Displayed |
| After One Second Time Delay | 0 8 5 | Stored Value For The Function Is Displayed |
| Push CONT | 0 8 5 | Display Value Will Blink |
| Change Value With Adjustment Knob | 1 2 5 | Value Changes While Blinking |
| Push STORE | 1 2 5 | New Value Stored And Blinking Stops |
| Push ESC | 8 8 8 8 | Segment Check Displayed |


At this point, another function can be monitored/changed by pushing another function number, or the vehicle can be placed in the run mode by holding the **ESC** key down for one second or longer. The display will return to either the diagnostics mode, the BDI display, or a blank display (if BDI is not used and there are no fault codes). The vehicle can now be operated with the Handset connected, or the Handset can be disconnected before operation.

NOTE: You can return to the segment check mode at any time, by holding down the **ESC** key until 8888 appears in the display.


Section 5.3.2 Status Code Scrolling

The SX family of controllers furnishes a function register that contains the last 16 "stored status codes" that shut down vehicle operation (a PMT type fault that is reset by cycling the key switch) and the battery state of charge reading at the time the fault occurred. The first of the 16


status codes will be overwritten each time a new status code occurs. This stored status code register can be cleared from memory by using the Handset.



Section 5.3.3 SX Family Handset, Plug Connections and Outline Drawing



Handset Cable Part Number - 325B1002G1 (12 pin plug)
Handset Part Number - IC3645LXHS1EC2 (12 pin plug)
(includes handset, cable and case)



Section 5.4 Setup Functions for Traction Controller

FUNCTION 1 MODE SELECT (Push 1)

This function allows for the selecting the controller operating mode as 1, 2, 3 or 4:

| Mode | Setting |
|------|-----------|
| 1 | 0 to 31 |
| 2 | 32 to 63 |
| 3 | 64 to 95 |
| 4 | 96 to 255 |

FUNCTION 2 CREEP SPEED (Push 2)

This function allows for the adjustment of the creep speed of the vehicle. Creep speed can be adjusted when an accelerator input voltage between 3.9 and 3.3 volts or an accelerator ohm input between 6K and 4.0K ohms is provided.

Range 2% to 15% on time
Set 0 to 255
Resolution 0.05% per set unit
Example: Setting of 20 = 3% on time

Important Note: This function is used to optimize motor and control performance and this setting will be determined by GE and OEM engineers at the time of vehicle development. This setting must not be changed by field personnel without the permission of the OEM.

FUNCTION 3 ARMATURE CONTROLLED ACCELERATION (Push 3)

This function allows for the adjustment of the rate of time it takes for the control to accelerate to 100% applied battery voltage to the motor on hard acceleration.

Range 0.1 to 25.5 seconds
Set 0 to 255
Resolution 0.1 seconds per set unit
Example: Setting of 20 = 2.0 seconds

FUNCTION 4 ARMATURE CURRENT LIMIT (Push 4)

This function allows for the adjustment of the armature current limit of the control. The rating of the control will determine the range of adjustment for this function. Please refer to the specification sheets and current limit curves for the control used in your vehicle.

Range See control C/L curves
Set 0 to 255
Example: 0 = min. current, 255 = max. current

FUNCTION 5 PLUGGING CURRENT LIMIT (USED ONLY IN BELLY BUTTON FUNCTION) (Push 5)

This function allows for the adjustment of the plugging distance of the vehicle. The larger the current setting, the shorter the stopping distance.

| Min | Max | Set | Resolution Per Unit Value | Example: If Set at 20 |
|-----|-----|----------|---------------------------|-----------------------|
| 55 | 455 | 0 to 255 | 1.57 amps | 86.4 amps |

FUNCTION 6 NOT APPLICABLE

This function is not applicable to this control type and should not be adjusted.

FUNCTION 7 MINIMUM FIELD CURRENT

This function is set by mode settings 48, 52, 56, and 60.

**FUNCTION 8 MAX FIELD CURRENT
 (Push 8)**

This function allows for the adjustment of the maximum field current in order to obtain the maximum torque of the motor.

| Min | Max | Set | Resolution Per Unit Value | Example: If Set at 71 |
|-----|-----|-----------|---------------------------|-----------------------|
| 0 | 40 | 51 to 255 | 0.185 amps | 3.7 amps |

Important Note: This function is used to optimize motor and control performance, and this setting will be determined by GE and OEM engineers at the time of vehicle development. This setting must not be changed by field personnel without the permission of the OEM.

FUNCTION 9 REGEN BRAKING CURRENT LIMIT

This function is set by mode settings 51, 55, 59, and 63.

**FUNCTION 10 FIELD CURRENT FOR REGEN AND PLUG BRAKING
 (Push 10)**

This function allows for the adjustment of the field current to be used during the regen and plug braking modes.

| Min | Max | Set | Resolution Per unit value | Example If set at 71 |
|-----|-----|-----------|---------------------------|----------------------|
| 0 | 40 | 51 to 255 | .185 amps | 3.7 amps |

Important Note: This function is used to optimize motor and control performance and this setting will be determined by GE and OEM engineers at the time of vehicle development. This setting must not be changed by field personnel without the permission of the OEM.

**FUNCTION 11 MAINTENANCE CODE SPEED LIMIT
 (Push 11)**

This function allows for the adjustment of the speed limit (maximum battery volts to the motor) when the maintenance code is activated by the control card.

| | |
|------------|--------------------------------------|
| Range | 100% to 0% of battery volts |
| Set | 51 to 180 |
| Resolution | 0.78% per set unit |
| Example | Setting of 71 = 84% of battery volts |

**FUNCTION 12 WALK SPEED LIMIT
 (Push 12)**

This function allows for the adjustment of the speed limit (maximum battery volts to the motor) when the jack rabbit speed limit switch is open.

| | |
|------------|--------------------------------------|
| Range | 100% to 0% of battery volts |
| Set | 51 to 180 |
| Resolution | 0.78% per set unit |
| Example | Setting of 71 = 84% of battery volts |

**FUNCTION 13 FORKS FORWARD SPEED LIMIT
 (Push 13)**

This function allows for the adjustment of the forks forward speed limit (maximum battery volts to the motor) when the jack rabbit speed limit switch is closed and the reverse switch is closed.

| | |
|------------|--------------------------------------|
| Range | 100% to 0% of battery volts |
| Set | 51 to 180 |
| Resolution | 0.78% per set unit |
| Example | Setting of 71 = 84% of battery volts |

**FUNCTION 14 INTERNAL RESISTANCE COMPENSATION
 (Push 14)**

This function is used when the Battery Discharge Indicator is present. Adjustment of this function will improve the accuracy of the BDI. In order to determine this setting the voltage drop of the battery under load must first be calculated by the following method.

1. On a fully charged battery, record the open circuit voltage (V_o) by measuring the voltage at the control positive and negative power terminals.
2. Load the traction motor to 100 amps, and record the voltage (V_L) at the control positive and negative power terminal.
3. Calculate voltage drop (V_{Drop}) as follows:
$$V_{Drop} = V_o - V_L$$
4. Use the table below to determine the appropriate setting using the calculated V_{Drop} as a reference.

**INTERNAL RESISTANCE COMPENSATION
TABLE**

| Setting | V _{Drop} | Setting | V _{Drop} |
|---------|-------------------|---------|-------------------|
| 2 | 11.44 | 17 | 01.34 |
| 3 | 07.60 | 18 | 01.27 |
| 4 | 05.72 | 19 | 01.20 |
| 5 | 04.57 | 20 | 01.14 |
| 6 | 03.81 | 21 | 01.09 |
| 7 | 03.27 | 22 | 01.04 |
| 8 | 02.86 | 23 | 00.99 |
| 9 | 02.54 | 24 | 00.95 |
| 10 | 02.28 | 25 | 00.91 |
| 11 | 02.08 | 26 | 00.88 |
| 12 | 01.90 | 27 | 00.85 |
| 13 | 01.76 | 28 | 00.82 |
| 14 | 01.63 | 29 | 00.79 |
| 15 | 01.52 | 30 | 00.76 |
| 16 | 01.43 | 31 | 00.74 |

**FUNCTION 15 BATTERY VOLTS
(Push I5)**

This function allows for the adjustment of voltage range for controls equipped with the Battery Discharge Indication function. In order for the BDI to operate properly, the setting as shown in the table must be entered:

| Battery volts | Set units |
|---------------|-------------------|
| 24 volts | Between 0 and 31 |
| 36 volts | Between 32 and 44 |

The following functions have function numbers larger than the numbers on the Handset keyboard. To access these functions. Push the CONT key and the number shown in the following instructions at the same time. THE BRAKE SWITCH MUST BE OPEN.

**FUNCTION 16 PEDAL POSITION PLUG AND REGEN
(Push CONT 1)**

This function allows for the adjustment of the pedal position braking. Pedal position will reduce the braking current to the current value set by this function as the accelerator is returned to the creep speed position. Maximum current is obtained with the accelerator in the top speed position.

| Min | Max | Set | Resolution Per unit value | Example If set at 100 |
|-----|-----|----------|------------------------------|--------------------------|
| 45 | 207 | 0 to 255 | 0.8125 per unit | 81.25 amps |

**FUNCTION 17 CARD TYPE SELECTION
(Push CONT 2)**

This function allows for the selection of the card type used for your vehicle's application. The table below shows the setting to select card application type, depending on which control card is used.

| Setting | Autobrake | Jog Switch | Pot Type | Rollback |
|------------|-----------|---------------|-----------|----------|
| 0 to 16 | No | No | 5K to 0 Ω | No |
| 17 to 32 | Yes | No | 5K to 0 Ω | No |
| 33 to 48 | No | Yes | 5K to 0 Ω | No |
| 49 to 64 | Yes | Yes | 5K to 0 Ω | No |
| 65 to 80 | No | No | 5K to 0 Ω | Yes |
| 81 to 96 | Yes | No | 5K to 0 Ω | Yes |
| 97 to 112 | No | Yes | 5K to 0 Ω | Yes |
| 113 to 127 | Yes | Yes | 5K to 0 Ω | Yes |

Settings for these functions should be made within the ranges indicated above.

Warning: These settings must be changed by authorized personnel only, following instructions supplied by the vehicle manufacturer. Card type selection must be made within the capabilities of the control panel used and the supporting electro mechanical devices. Failure to comply with proper application standards could result in mis-operation or damage to the control and/or motors.

FUNCTION 18 NOT APPLICABLE

This function is not applicable to this controller type and should not be adjusted.

**FUNCTION 19 MAINTENANCE CODE TENS AND UNITS
HOURS SET
(Push CONT 4)**

This function allows for the adjustment of the tens and units hours of the maintenance code activation time.

| | |
|---------|------------|
| Range | 0 to 99 |
| Set | 0 to 99 |
| Example | 9999 Hours |

FUNCTION 20 MAINTENANCE CODE THOUSANDS AND HUNDREDS HOURS SET (Push CONT 5)

This function allows for the adjustment of the thousands and hundreds hours of the maintenance code activation time.

Range 0 to 99
Set 0 to 99
Example 9999 Hours

FUNCTION 21 PUMP ENABLE (Push CONT 6)

This function enables or disables the BDI lift interrupt feature, which can be selected to occur at 9% battery state of charge.

| Setting | Description |
|------------|---|
| 0 to 127 | Enables BDI lift interrupt feature |
| 128 to 255 | Disables the BDI lift interrupt feature |

FUNCTION 22 NOT APPLICABLE

This function is not applicable to this controller type and should not be adjusted.

FUNCTION 23 MOTOR CURRENT DECAY RATE (Push CONT 8)

This function allows for the adjustment of the rate of decay of motor current after a neutral signal is received.

Range 0.1 to 1.6 seconds
Set 0 to 16
Resolution 0.1 seconds per set unit
Example: Setting of 10 = 1.0 second

FUNCTION 24 FIELD WEAKENING START (Push CONT 9)

This function is set by mode settings 49, 53, 57, and 61

FUNCTION 25 MONITOR (Push CONT 10)

This function allows the monitoring of certain control functions by looking directly at the RAM of the microprocessor. Because absolute memory locations need to be known, this function should not be used without detailed instructions from the GE application engineer.

This function should only be adjusted by the vehicle OEM. To ensure optimum operation of the control, this function must be left with zero stored in this register.

FUNCTION 26 RATIO (Push CONT 11)

This function is set by mode settings 50, 54, 58, and 62.

FUNCTION 27 NOT APPLICABLE

This function is not applicable to this controller type and should not be adjusted.

FUNCTION 28 STORED STATUS CODE COUNT POINTER (Push CONT 13)

This register contains the location of the last stored status code recorded of the 16 stored status codes. These stored status codes have caused a PMT controller shutdown and/or disruption of normal vehicle operation.

To determine which stored status code was the last one recorded, read the number stored in Function 28. Using the **Memory Map** for your logic card, match the "**stored status code pointer number**" [the number shown in (*bold italics*) in the HS (Handset) number column] on the memory map, with the number obtained from Function 28. This will be the last stored status code recorded.

Note: **When scrolling through the stored status code register, the register always starts at status code 1 and scrolls to status code 16. Instructions for scrolling the register are in section 5.3.2 of this instruction booklet.**

FUNCTION 29 HOUR METER TENS AND UNITS HOURS SET (Push CONT 14)

This function allows for the adjustment of the tens and units hours of the displayed hour meter.

Range 0 to 99
Set 0 to 99
Example 9999 Hours

FUNCTION 30 HOUR METER THOUSANDS AND HUNDREDS HOURS SET (Push CONT 15)

This function allows for the adjustment of the thousands and hundreds hours of the displayed hour meter.

Range 0 to 99
Set 0 to 99
Example 9999 Hours

DASH DISPLAY INTERACTIVE MODES

The following functions (functions 48 through 62) are mode settings that are activated from the Interactive Dash Display. Each function must be set using the logic table shown below. If you try to set this function outside these guidelines, an error code will be displayed to prompt you to enter the correct setting:

- If "80" is displayed, the setting is too low.
- If "81" is displayed, the setting is too high.

**FUNCTION 48 MODE 1 MIN FIELD CURRENT
(Push CONT 1)**

This function allows the adjustment of the field weakening level in order to set the top speed of the motor.

| Min | Max | Set | Resolution Per Unit Value | Example If Set at 71 |
|-----|-----|-----------|---------------------------|----------------------|
| 0 | 40 | 51 to 255 | 0.185 amps | 3.7 amps |

Important Note: This function is used to optimize motor and control performance, and this setting will be determined by GE and OEM engineers at the time of vehicle development. This setting must not be changed by field personnel without the permission of the OEM.

This MIN FIELD CURRENT takes effect when the Mode 1 settings are selected by Function 1.

**FUNCTION 49 MODE 1 FIELD WEAKENING START
(Push CONT 2)**

This function allows for setting the armature current at which minimum field current will be achieved.

- Range 0 to 240 Amps
- Setting 0 to 147
- Resolution 1.625 per set unit
- Example Setting of 20 = 32.5 amps

$$I_{M\ FWS} = VAL \times 1.625$$

Important Note: This function is used to optimize motor and control performance and this setting will be determined by GE and OEM engineers at the time of vehicle development. This setting must not be changed by field personnel without the permission of the OEM.

This FIELD WEAKENING START takes effect when the Mode 1 settings are selected by Function 1.

*The following functions have function numbers larger than the numbers on the Handset keyboard. To access these functions. Push the CONT key and the number shown in the following instructions at the same time.
THE BRAKE SWITCH MUST BE CLOSED.*

**FUNCTION 50 MODE 1 RATIO
(Push CONT 3)**

This function sets the ratio between armature and field current when transitioning from minimum field to maximum field current. The setting represents the quantity of field current changed for each 100 amps of armature current changed.

| Max fld Ref | Set | Resolution Per Unit Value | Example If Set at 5 |
|-------------|---------|---------------------------|---------------------|
| 40 | 0 to 10 | 1.48 amps | 7.4 amps |

This RATIO takes effect when the Mode 1 settings are selected by Function 1.

**FUNCTION 51 MODE 1 REGEN BRAKING C/L
(Push CONT 4)**

This function allows for the adjustment of the Regen braking current limit. The higher the current, the shorter the stopping distance.

| Min | Max | Set | Resolution Per unit value | Example If set at 20 |
|-----|-----|----------|---------------------------|----------------------|
| 52 | 468 | 0 to 255 | 1.63 amps | 84.6 amps |

This REGEN BRAKING C/L takes effect when the Mode 1 settings are selected by Function 1.

**FUNCTION 52 MODE 2 MIN FIELD CURRENT
(Push CONT 5)**

Same as Function 48.

This MIN FIELD CURRENT takes effect when the Mode 2 settings are selected by Function 1.

**FUNCTION 53 MODE 2 FIELD WEAKENING START
(Push CONT 6)**

Same as Function 49.

This FIELD WEAKENING START takes effect when the Mode 2 settings are selected by Function 1.

FUNCTION 54 MODE 2 RATIO
(Push CONT 7)

Same as Function 50.

This RATIO takes effect when the Mode 2 settings are selected by Function 1.

FUNCTION 55 MODE 2 REGEN BRAKING C/L
(Push CONT 8)

Same as Function 51.

This REGEN BRAKING C/L takes effect when the Mode 2 settings are selected by Function 1.

FUNCTION 56 MODE 3 MIN FIELD CURRENT
(Push CONT 9)

Same as Function 48.

This MIN FIELD CURRENT takes effect when the Mode 3 settings are selected by Function 1.

FUNCTION 57 MODE 3 FIELD WEAKENING START
(Push CONT 10)

Same as Function 49.

This FIELD WEAKENING START takes effect when the Mode 3 settings are selected by Function 1.

FUNCTION 58 MODE 3 RATIO
(Push CONT 11)

Same as Function 50.

This RATIO takes effect when the Mode 3 settings are selected by Function 1.

FUNCTION 59 MODE 3 REGEN BRAKING C/L
(Push CONT 12)

Same as Function 51.

This REGEN BRAKING C/L takes effect when the Mode 3 settings are selected by Function 1.

FUNCTION 60 MODE 4 MIN FIELD CURRENT
(Push CONT 13)

Same as Function 48.

This MIN FIELD CURRENT takes effect when the Mode 4 settings are called selected by Function 1.

FUNCTION 61 MODE 4 FIELD WEAKENING START
(Push CONT 14)

Same as Function 49.

This FIELD WEAKENING START takes effect when the Mode 4 settings are selected by Function 1.

FUNCTION 62 MODE 4 RATIO
(Push CONT 15)

Same as Function 50.


This RATIO takes effect when the Mode 4 settings are selected by Function 1.

FUNCTION 63 MODE 4 REGEN BRAKING C/L
(Push CONT ESC)

Same as Function 51.

This REGEN BRAKING C/L takes effect when the Mode 4 settings are selected by Function 1.

Section 5.5 Summary of Current Limit Adjustments




Section 6.0 DASH DISPLAYS

Section 6.1 Application

The SX family Standard and Interactive Dash Displays allow the operator and maintenance personnel easy access to truck operation information and real-time system diagnostics of the controller, motor and various accessories. Hourmeter readings, battery discharge information, maintenance information and system status codes are clearly displayed during startup and running modes. Shielded cable connections are made to the Dash Display by means of five (5) 22-gage wires to the "Y" Plug of the traction and hydraulic pump controls.

Section 6.2 Standard Dash Displays




The GE Standard Dash Display is a four segment Light Emitting Diode (LED) instrument that displays the GE LX, ZX, and SX Status Codes, Hourmeter Readings, Battery Discharge Indication, and Maintenance Required Code. The four LED's above the symbols indicate the active readout mode.

Section 6.2.1 Connections

Connections are made to the Dash Display with five (5) 22-gage wires to Plug "Y" of each control. Shielded cable is required to eliminate signal interference.


Section 6.2.2 Part Number




Section 6.2.3 Connector Reference Numbers

- AMP#102241-3 Dash Display mating plug
- AMP#1-87195-8 Dash Display mating pin
- 44A723596-G09 Dash Display plug kit
- AMP#175965-2 "Y" Plug
- AMP#175180-1 "Y" Plug receptacle

Section 6.3 Start-Up Display Sequence



Section 6.4 Outline Drawings



Section 7.0 MEMORY MAPS

Section 7.1 Traction Control

| E ² | Func No. | HS No. | Traction Control Function | Access By | Restrictions |
|----------------|----------|--------|--|-----------|----------------------|
| 0 | 1 | 1 | Mode Select | HS or PC | None |
| 1 | 2 | 2 | Creep Speed | HS or PC | None |
| 2 | 3 | 3 | Armature Controlled Acceleration | HS or PC | None |
| 3 | 4 | 4 | Armature Current Limit | HS or PC | None |
| 4 | 5 | 5 | Plugging Current Limit | HS or PC | None |
| 5 | 6 | 6 | Not applicable | HS or PC | None |
| 6 | 7 | 7 | Not applicable | HS or PC | None |
| 7 | 8 | 8 | Max Field Current | HS or PC | None |
| 8 | 9 | 9 | Not Applicable | HS or PC | None |
| 9 | 10 | 10 | Field Current for Regen and Plug Braking | HS or PC | None |
| 10 | 11 | 11 | Maintenance Code Speed Limit | HS or PC | None |
| 11 | 12 | 12 | Walk Speed Limit | HS or PC | None |
| 12 | 13 | 13 | Forks Forward Speed Limit | HS or PC | None |
| 13 | 14 | 14 | IR Compensation | HS or PC | None |
| 14 | 15 | 15 | Battery Volts Select | HS or PC | None |
| 15 | 16 | 16 | Pedal Position Plug and Regen | HS or PC | None |
| 16 | 17 | 17 | Card Type Selection | HS or PC | None |
| 17 | 18 | 18 | Not applicable | HS or PC | None |
| 18 | 19 | 19 | Maintenance Code HM (Tens/Units) | HS or PC | None |
| 19 | 20 | 20 | Maintenance Code HM (Thou/Hun) | HS or PC | None |
| 20 | 21 | 21 | Pump Enable | HS or PC | None |
| 21 | 22 | 22 | Not applicable | HS or PC | For DD on power up |
| 22 | 23 | 23 | Not applicable | HS or PC | None |
| 23 | 24 | 24 | Not applicable | HS or PC | None |
| 24 | 25 | 25 | Monitor | HS or PC | GE Temporary Storage |
| 25 | 26 | 26 | Ratio | HS or PC | GE Temporary Storage |
| 26 | 27 | 27 | Not applicable | HS or PC | GE Temporary Storage |
| 27 | 28 | 28 | Fault Count Pointer | HS or PC | None |
| 28 | 29 | 29 | Hour Meter Tens and Units | HS or PC | None |
| 29 | 30 | 30 | Hour Meter Thousands and Hundreds | HS or PC | None |
| 30 | 31 | | Aux HM (Tens/Ones) | PC Only | None |
| 31 | 32 | | Aux HM (Thou/Hun) | PC Only | None |
| 32 | 33 | (18) | Stored Status Code #1 | PC Only | Reset to Zero Only |
| 33 | 34 | | BDI 1 | PC Only | Reset to Zero Only |
| 34 | 35 | | Hours (Tens/Ones) 1 | PC Only | Reset to Zero Only |
| 35 | 36 | | Hours (Thou/Hun) 1 | PC Only | Reset to Zero Only |
| 36 | 37 | (20) | Stored Status Code #2 | PC Only | Reset to Zero Only |
| 37 | 38 | | BDI 2 | PC Only | Reset to Zero Only |
| 38 | 39 | | Hours (Tens/Ones) 2 | PC Only | Reset to Zero Only |
| 39 | 40 | | Hours (Thou/Hun) 2 | PC Only | Reset to Zero Only |
| 40 | 41 | (22) | Stored Status Code #3 | PC Only | Reset to Zero Only |
| 41 | 42 | | BDI 3 | PC Only | Reset to Zero Only |
| 42 | 43 | | Hours (Tens/Ones) 3 | PC Only | Reset to Zero Only |

| E ² | Func No. | HS No. | Traction Control Function | Access By | Restrictions |
|----------------|----------|--------|---------------------------|-----------|--------------------|
| 43 | 44 | | Hours (Thou/Hun) 3 | PC Only | Reset to Zero Only |
| 45 | 46 | | BDI 4 | PC Only | Reset to Zero Only |
| 46 | 47 | | Hours (Tens/Ones) 4 | PC Only | Reset to Zero Only |
| 47 | 48 | | Hours (Thou/Hun) 4 | PC Only | Reset to Zero Only |
| 48 | 49 | (26) | Stored Status Code #5 | PC Only | Reset to Zero Only |
| 49 | 50 | | BDI 5 | PC Only | Reset to Zero Only |
| 50 | 51 | | Hours (Tens/Ones) 5 | PC Only | Reset to Zero Only |
| 51 | 52 | | Hours (Thou/Hun) 5 | PC Only | Reset to Zero Only |
| 52 | 53 | (28) | Stored Status Code #6 | PC Only | Reset to Zero Only |
| 53 | 54 | | BDI 6 | PC Only | Reset to Zero Only |
| 54 | 55 | | Hours(Tens/Ones) 6 | PC Only | Reset to Zero Only |
| 55 | 56 | | Hours(Thou/Hun) 6 | PC Only | Reset to Zero Only |
| 56 | 57 | (30) | Stored Status Code #7 | PC Only | Reset to Zero Only |
| 57 | 58 | | BDI 7 | PC Only | Reset to Zero Only |
| 58 | 59 | | Hours(Tens/Ones) 7 | PC Only | Reset to Zero Only |
| 59 | 60 | | Hours(Thou/Hun) 7 | PC Only | Reset to Zero Only |
| 60 | 61 | (32) | Stored Status Code #8 | PC Only | Reset to Zero Only |
| 61 | 62 | | BDI 8 | PC Only | Reset to Zero Only |
| 62 | 63 | | Hours;(Tens/Ones) 8 | PC Only | Reset to Zero Only |
| 63 | 64 | | Hours(Thou/Hun) 8 | PC Only | Reset to Zero Only |
| 64 | 65 | (34) | Stored Status Code #9 | PC Only | Reset to Zero Only |
| 65 | 66 | | BDI 9 | PC Only | Reset to Zero Only |
| 66 | 67 | | Hours(Tens/Ones) 9 | PC Only | Reset to Zero Only |
| 67 | 68 | | Hours(Thou/Hun) 9 | PC Only | Reset to Zero Only |
| 68 | 69 | (36) | Stored Status Code #10 | PC Only | Reset to Zero Only |
| 69 | 70 | | BDI 10 | PC Only | Reset to Zero Only |
| 70 | 71 | | Hours(Tens/Ones) 10 | PC Only | Reset to Zero Only |
| 71 | 72 | | Hours(Thou/Hun) 10 | PC Only | Reset to Zero Only |
| 72 | 73 | (38) | Stored Status Code #11 | PC Only | Reset to Zero Only |
| 73 | 74 | | BDI 11 | PC Only | Reset to Zero Only |
| 74 | 75 | | Hours(Tens/Ones) 11 | PC Only | Reset to Zero Only |
| 75 | 76 | | Hours(Thou/Hun) 11 | PC Only | Reset to Zero Only |
| 76 | 77 | (40) | Stored Status Code #12 | PC Only | Reset to Zero Only |
| 77 | 78 | | BDI 12 | PC Only | Reset to Zero Only |
| 78 | 79 | | Hours(Tens/Ones) 12 | PC Only | Reset to Zero Only |
| 79 | 80 | | Hours(Thou/Hun) 12 | PC Only | Reset to Zero Only |
| 80 | 81 | (42) | Stored Status Code #13 | PC Only | Reset to Zero Only |
| 81 | 82 | | BDI 13 | PC Only | Reset to Zero Only |
| 82 | 83 | | Hours(Tens/Ones) 13 | PC Only | Reset to Zero Only |
| 83 | 84 | | Hours(Thou/Hun) 13 | PC Only | Reset to Zero Only |
| 84 | 85 | (44) | Stored Status Code # 14 | PC Only | Reset to Zero Only |
| 85 | 86 | | BDI 14 | PC Only | Reset to Zero Only |
| 86 | 87 | | Hours(Tens/Ones) 14 | PC Only | Reset to Zero Only |
| 87 | 88 | | Hours(Thou/Hun) 14 | PC Only | Reset to Zero Only |
| 88 | 89 | (46) | Stored Status Code # 15 | PC Only | Reset to Zero Only |
| 89 | 90 | | BDI 15 | PC Only | Reset to Zero Only |
| 90 | 91 | | Hours (Tens/Ones) 15 | PC Only | Reset to Zero Only |

| E ² | Func No. | HS No. | Traction Control Function | Access By | Restrictions |
|----------------|----------|-------------|------------------------------------|-----------|--------------------|
| 90 | 91 | | Hours (Tens/Ones) 15 | PC Only | Reset to Zero Only |
| 91 | 92 | | Hours (Thou/Hun) 15 | PC Only | Reset to Zero Only |
| 92 | 93 | (48) | Stored Status Code #16 | PC Only | Reset to Zero Only |
| 94 | 95 | | Hours (Tens/Ones) 16 | PC Only | Reset to Zero Only |
| 95 | 96 | | Hours (Thou/Hun) 16 | PC Only | Reset to Zero Only |
| 96 | 97 | 48 | Mode 1 Min Field Current | HS or PC | None |
| 97 | 98 | 49 | Mode 1 Field Weakening Start | HS or PC | None |
| 98 | 99 | 50 | Mode 1 Ratio | HS or PC | None |
| 99 | 100 | 51 | Mode 1 Regen Braking Current Limit | HS or PC | None |
| 100 | 101 | 52 | Mode 2 Min Field Current | HS or PC | None |
| 101 | 102 | 53 | Mode 2 Field Weakening Start | HS or PC | None |
| 102 | 103 | 54 | Mode 2 Ratio | HS or PC | None |
| 103 | 104 | 55 | Mode 2 Regen Braking Current Limit | HS or PC | None |
| 104 | 105 | 56 | Mode 3 Min Field Current | HS or PC | None |
| 105 | 106 | 57 | Mode 3 Field Weakening Start | HS or PC | None |
| 106 | 107 | 58 | Mode 3 Ratio | HS or PC | None |
| 107 | 108 | 59 | Mode 3 Regen Braking Current Limit | HS or PC | None |
| 108 | 109 | 60 | Mode 4 Min Field Current | HS or PC | None |
| 109 | 110 | 61 | Mode 4 Field Weakening Start | HS or PC | None |
| 110 | 111 | 62 | Mode 4 Ratio | HS or PC | None |
| 111 | 112 | 63 | Mode 4 Regen Braking Current Limit | HS or PC | None |
| 112 | 113 | | Secure HM (Tens/Ones) | PC Only | OEM Read Only |
| 113 | 114 | | Secure HM (Thou/Hun) | PC Only | OEM Read Only |
| 114 | 115 | | Secure Aux HM (Tens/Ones) | PC Only | OEM Read Only |
| 115 | 116 | | Secure Aux HM (Thou/Hun) | PC Only | OEM Read Only |
| 116 | 117 | | Reserved | PC Only | GE Future Use |
| 117 | 118 | | Reserved | PC Only | GE Future Use |
| 118 | 119 | | Reserved | PC Only | GE Future Use |
| 119 | 120 | | Reserved | PC Only | GE Future Use |
| 120 | 121 | | OEM Use | PC Only | None |
| 121 | 122 | | OEM Use | PC Only | None |
| 122 | 123 | | OEM Use | PC Only | None |
| 123 | 124 | | OEM Use | PC Only | None |
| 124 | 125 | | OEM Use | PC Only | None |
| 125 | 126 | | OEM Use | PC Only | None |
| 126 | 127 | | OEM Use | PC Only | None |
| 127 | 128 | | OEM Use | PC Only | None |

Numbers in ***(bold italics)*** are Stored Status Code pointers.