



- ① Main Switch
- ② Tow/storage switch
- ③ Accelerator stop switch
- ④ Buzzer
- ⑤ Directional switch
- ⑥ DC motor
- ⑦ Controller
- ⑧ Throttle sensor
- ⑨ Relay
- ⑩ Receptacle
- ⑪ Fuse (3A)
- ⑫ Batteries (6 X 8V)

COLOR CODE

B.....	Black
L.....	Blue
G.....	Green
Y.....	Yellow
R.....	Red
P.....	Pink
Br.....	Brown
W.....	White
B/R.....	Black/Red
Y/B....	Yellow/Black
R/Y.....	Red/Yellow
R/W.....	Red/White

YAMAHA G19/G22
WIRING DIAGRAM (FX503)