


**SEPARATELY EXCITED (SX) TRANSISTORIZED TRACTION MOTOR CONTROL
 AND SERIES PUMP MOTOR CONTROL
 INSTALLATION AND OPERATION MANUAL
 (IC3645SR4W746N5 and IC3645SP4U450N10)**



Note: The information contained herein is intended to assist OEM's, Dealers and Users of electric vehicles in the application, installation and service of GE solid-state controllers. This manual does not purport to cover all variations in OEM vehicle types. Nor does it provide for every possible contingency to be met involving vehicle installation, operation or maintenance. For additional information and/or problem resolution, please refer the matter to the OEM vehicle manufacturer through his normal field service channels. Do not contact GE directly for this assistance.

Table of Contents

General Electric Company October 2002

Section 1.0	INTRODUCTION	4
	1.1 Motor Characteristics	4
	1.2 Solid-State Reversing	5
	1.3 Flexible System Application	5
	1.4 More Features with Fewer Components	5
Section 2.0	FEATURES OF SX FAMILY OF MOTOR CONTROLLERS.....	6
	2.1 Performance	6
	2.1.1 Oscillator Card Features.....	6
	2.1.1.a Standard Operation	6
	2.1.1.b Creep Speed	6
	2.1.1.c Controlled Acceleration and 1A Time	6
	2.1.2 Current Limit.....	6
	2.1.3 Braking.....	6
	2.1.3.a Plug Braking	6
	2.1.3.b Regenerative Braking to Zero Speed	6

Table of Contents (Continued)

2.1.3.c	Pedal Position Plug Braking	6
2.1.3.d	Auto Braking.....	6
2.1.3.e	Brake Pedal Regenerative Braking	6
2.1.4	Auxiliary Speed Control.....	6
2.1.4.a	Field Weakening	6
2.1.4.b	Speed Limits	7
2.1.5	Ramp Operation	7
2.1.5.a	Ramp Start	7
2.1.5.b	Anti-Rollback.....	7
2.1.6	On-Board Coil Drivers and Internal Coil Suppression	7
2.2	System Protective Override.....	7
2.2.1	Static Return to Off (SRO)	7
2.2.2	Accelerator Volts Hold Off.....	7
2.2.3	Pulse Monitor Trip (PMT).....	7
2.2.4	Thermal Protector (TP).....	7
2.2.5	Low Voltage	7
2.3	Diagnostics.....	8
2.3.1	Systems Diagnostics.....	8
2.3.2	Status Codes.....	8
2.3.2.a	Standard Codes.....	8
2.3.2.b	Stored Codes	8
2.3.3	Hourmeter Readings	8
2.3.3.a	Maintenance Alert and Speed Limit	8
2.3.4	Battery Discharge Indication (BDI).....	8
2.3.4.a	Internal Resistance Compensation	8
2.3.5	Handset	8
2.3.6	RS-232 Communication Port	8
2.3.6.a	Dash Display Interaction Modes	8
2.3.7	Circuit Board Coil Driver Modules.....	9
2.3.8	Truck Management Module (TMM).....	9
2.4	Hydraulic Pump Control.....	9
Section 3.0	ORDERING INFORMATION, ELEMENTARY AND OUTLINE DRAWINGS	10
3.1	Ordering Information for Separately Excited Controls.....	10
3.2	Outline: SX-4 Package Size	11
3.3	Outline: SX-3 and SR-3 Package Size.....	12
3.4	Traction Elementary	13
3.5	Pump Elementary	14
3.6	Traction and Pump Control Input / Output List.....	15
Section 4.0	TROUBLESHOOTING AND DIAGNOSTIC STATUS CODES	16
4.1	General Maintenance Instructions	16
4.2	Cable Routing and Separation	16
4.2.1	Application Responsibility	16
4.2.2	Signal/Power Level Definitions.....	16
4.2.2.a	Low Level Signals (Level L).....	16
4.2.2.b	High Level Signals (Level H).....	17
4.2.2.c	Medium-Power Signals (Level MP).....	17
4.2.2.d	High-Power Signals (Level HP).....	17
4.2.3	Cable Spacing Guidelines	17

Table of Contents (Continued)

4.2.3.a	General Cable Spacing	17
4.2.4	Cabling for Vehicle Retrofits	17
4.2.5	RF Interference.....	17
4.2.6	Suppression	17
4.3	Recommended Lubrication of Pins and Sockets Prior to Installation.....	18
4.4	Controller Mounting Guidelines.....	19
4.4.1	Necessary Tools	19
4.4.2	The GE Control Mounting Surface	19
4.4.3	Vehicle Mounting Surface.....	19
4.4.4	Application of Thermal Compound.....	19
4.4.5	Mounting the GE Control.....	20
4.4.6	Maintenance	20
4.5	General Troubleshooting Instructions	20-21
4.6	Traction Controller Status Codes	22-38
4.7	TMM Module Status Codes	39-43
4.8	Pump Control Status Codes.....	44-50
Section 5.0	TRUCK MANAGEMENT MODULE (TMM)	51
5.1	General Features	51
5.2	Operation	51
5.3	Installation.....	51
5.4	Connection Diagrams	51
5.4.1	TMM7A Card Connections.....	51
5.4.2	TMM7A Typical Brush Wear Sensor Connections	51
5.4.3	TMM Pump Control Connections	52
5.5	TMM7A Outline Drawings	52
Section 6.0	SX FAMILY - GE HANDSET INSTRUCTIONS.....	53
6.1	General Features	53
6.2	Purpose/Setup Functions	53
6.3	Setup Function Procedures	54
6.3.1	Setup Mode	54
6.3.2	Status Code Scrolling.....	54
6.3.3	SX Handset Plug Connections & Outline Drawing.....	54
6.4	Setup Functions for Traction Controller	55-60
6.5	Summary of Current Limit Adjustments.....	61
6.6	Setup Functions for Hydraulic Pump Controller	62-64
Section 7.0	DASH DISPLAYS.....	65
7.1	Application	65
7.2	Standard Dash Displays	65
7.3	Interactive Dash Displays.....	65
7.4	Start-up Display Sequence	66
7.5	Outline Drawings	66
Section 8.0	MEMORY MAPS.....	67
8.1	Typical Memory Map for Traction Control.....	67-69